

# PS14 - Remove Waxes and Floor Finishes

Remove Waxes & Floor Finishes from Natural Stone, Ceramic & Porcelain Tiles

## Remove Light/Regular Wax Coatings & Floor Finishes

**PRODUCT:** **MICROSCRUB™**

**EQUIPMENT:** AquaBug Cleaning Kit, Scrub pad or brush, broom, bucket, clean water and cotton towels. Optional: Scrub machine, wet-dry vac.



**PRECAUTIONS:**

1. Read entire label, SDS & technical bulletin before using;
2. Wear appropriate skin & eye protection;
3. Use when surface temperature is between 4°C & 32°C;
4. Do not allow product to contact any non-recommended surfaces;
5. Take care when using on dark coloured grout or stone;

**PROCEDURE:**

1. Sweep, vacuum, or wipe surface;
2. Slightly pre-wet surface & grout joints with clean water;
3. Pour approx 1-2 cups of **MicroScrub™** to the pre wet surface;
4. Scrub the surface with a white nylon pad, scrub brush or scrub machine;
5. For vertical surfaces, pre-wet surface by spraying water from a spray bottle then apply **MicroScrub™** directly to a white nylon pad then scrub;
6. **DO NOT ALLOW PRODUCT TO DRY ON THE SURFACE;**
7. Remove the dirty solution with a wet vac or mop;
8. Rinse thoroughly with clean water;
9. Repeat as necessary.

## Remove Heavy Wax Coatings & Floor Finishes

**PRODUCT:** **MICROSCRUB™ with XTREMECLEAN™**

**EQUIPMENT:** AquaBug Cleaning Kit, Scrub pad or brush, broom, bucket, clean water and cotton towels. Optional: Scrub machine, wet-dry vac.



**PRECAUTIONS:**

1. Read entire label, SDS & technical bulletin before using;
2. Wear appropriate skin & eye protection;
3. Use when surface temperature is between 4°C & 32°C;
4. Do not allow product to contact any non-recommended surfaces;
5. Take care when using **MicroScrub™** on dark coloured grout or stone;
6. Do NOT use **XtremeClean™** undiluted.

**PROCEDURE:**

1. Sweep, vacuum, or wipe surface;
2. Dilute **XtremeClean™** as follows depending on the severity of the problem:
  - a) **HEAVY:** Dilute 1 part **XtremeClean™** to 5 parts clean water ;
  - b) **VERY HEAVY:** Dilute 1 part **XtremeClean™** to 3 parts clean water;
3. Carefully apply the solution to surface with a sponge or a mop;
4. Allow minimum dwell time of 10 minutes. Longer dwell time may be required.
5. **DO NOT ALLOW THE PRODUCT TO DRY ON THE SURFACE;**
6. Scrub with a white nylon pad, scrub brush or scrub machine;
7. Remove the dirty solution with a wet vac or mop;
8. Rinse thoroughly with clean water;
9. Repeat the process as necessary.

NOTE: Add **MicroScrub™** to standing solution just prior to scrubbing (after Step 4) to boost performance where required.



**Note A:** For extreme heavy wax coatings or floor finishes, use **Strip-It** as per label instructions.

This recommendation is intended as a general guideline. The actual procedure requirements, dilution ratios, dwell time etc may vary depending on type of surface, method of application and severity of the problem.

READ PRODUCT LABEL INSTRUCTIONS, TECHNICAL BULLETIN & SDS THOROUGHLY BEFORE USING. ALWAYS TEST FIRST.  
KEEP SURFACE CLEAN AND DRY TO REDUCE THE POSSIBILITY OF SLIP & FALL ACCIDENTS AND INJURIES