

PS16 - Remove Smoke, Soot, Hydrocarbons, Red Soil

Remove Smoke, Soot, Hydrocarbons, Red Soil from Natural Stone, Porcelain Tiles, Pavers etc

PRODUCT: **BLAST HD™**

EQUIPMENT: AquaBug Cleaning Kit, Scrub pad or brush, broom, bucket, clean water and cotton towels. Optional: Scrub machine, wet-dry vac.



PRECAUTIONS:

1. Read entire label, SDS & technical bulletin before using;
2. Wear appropriate skin & eye protection & use in a well ventilated area;
3. Surface must be clean, dry & free from any sealers & coatings;
4. Use when surface temperature is between 4°C & 32°C;
5. Do NOT mix with other chemicals or allow contact with any non-recommended surfaces;
6. Do NOT use on acid sensitive or polished surfaces;
7. Do NOT mix in metal containers;
8. Remove all metal jewellery before using;

PROCEDURE:

1. Sweep, vacuum, or wipe surface;
2. If the surface is very porous, slightly pre-wet surface with water;
3. Dilute **Blast HD™** as follows:
 - a) LIGHT: Mix 1 part product to 8 parts water;
 - b) MODERATE: Mix 1 part product to 5 parts water;
 - c) HEAVY: Mix 1 part product to 3 parts water;
 - d) EXTREME: Mix 1 part product to 1 part water or use neat;
4. Carefully apply solution to surface with a sponge, roller or mop;
5. Allow minimum dwell time of 10 minutes - up to 30 minutes
6. **DO NOT ALLOW THE PRODUCT TO DRY ON THE SURFACE;**
7. Scrub with a white nylon pad, scrub brush or scrub machine;
8. Remove the dirty solution with a wet vac or mop;
9. Rinse thoroughly with clean water;
10. Repeat the process as necessary.

Note 1: Heavily soiled areas may require longer dwell time and/or stronger solution.

Note 2: Some stained surfaces may require resurfacing or replacing;

Note A: Do NOT use **Blast HD™** on polished marble, limestone, travertine or on other acid-sensitive tile or stone.

This recommendation is intended as a general guideline. The actual procedure requirements, dilution ratios, dwell time etc may vary depending on type of surface, method of application and severity of the problem.

READ PRODUCT LABEL INSTRUCTIONS, TECHNICAL BULLETIN & SDS THOROUGHLY BEFORE USING. ALWAYS TEST FIRST.
KEEP SURFACE CLEAN AND DRY TO REDUCE THE POSSIBILITY OF SLIP & FALL ACCIDENTS AND INJURIES