

PS08 - Remove Deep Set Stains

Remove Stains from Natural Stone, Porcelain Tiles, Pavers etc

PURPOSE: Remove Stains - Small Areas

PRODUCT: **POULTICE PLUS™**

EQUIPMENT: Plastic Bowl, plastic spatula, Glad Wrap or Foil, AquaBug Cleaning Kit, Scrub pad or brush, broom, bucket, clean water and cotton towels.



PRECAUTIONS:

1. Always Test first;
2. Read entire label and product technical bulletin before using;
3. Wear appropriate skin protection.
4. Surface must be clean and completely dry and free from any other sealers and coatings;
5. Use when surface temperature is between 4°C & 32°C;

PROCEDURE:

1. Stir well before using as product may settle (mix to a creamy paste consistency);
2. Sweep, vacuum, or wipe surface;
3. Apply 6mm thickness of **Poultrice Plus™** in a uniform coat over stained area (cover an area slightly larger than actual stain);
4. Cover with foil or plastic wrap and tape down borders with glue residue free tape;
5. Poke a few holes in the surface of the foil or plastic wrap;
6. Allow **Poultrice Plus™** to remain covered until it dries - this may take 24-48 hours or longer, depending on conditions;
7. When dry, remove **Poultrice Plus™** from the surface with a plastic spatula;
8. Rinse thoroughly with clean water;
9. Repeat as necessary.

PURPOSE: Remove Stains - Large Areas

PRODUCT: **POULTICE POWDER™**

EQUIPMENT: Plastic Bowl, plastic spatula, Glad Wrap or Foil, AquaBug Cleaning Kit, Scrub pad or brush, broom, bucket, clean water and cotton towels.



PRECAUTIONS:

1. Always Test first;
2. Read entire label and product technical bulletin before using;
3. Wear appropriate skin protection.
4. Surface must be clean and completely dry and free from any other sealers and coatings;
5. Use when surface temperature is between 4°C & 32°C;

PROCEDURE:

1. Sweep, vacuum, or wipe surface;
2. Mix **Poultrice Powder™** with water to form a thick paste to a toothpaste consistency;
3. Apply 6mm of paste in a uniform coat over stained area (cover an area slightly larger than actual stain);
4. Cover with foil or plastic wrap and tape down borders with glue residue free tape;
5. Poke a few holes in the surface of the foil or plastic wrap;
6. Allow paste to remain covered until it dries - this may take 24-48 hours or longer, depending on conditions;
7. When dry, remove paste from the surface with a plastic spatula;
8. Rinse thoroughly with clean water to remove any residue;
9. Repeat as necessary.

NOTE: Depending on the type of stain or its severity, replace water with the appropriate Aqua-Seal STS Cleaner or Problem Solver product - refer to [Stain Removal Guide](#) at www.aqua-seal.com.au

This recommendation is intended as a general guideline. The actual procedure requirements, dilution ratios, dwell time etc may vary depending on type of surface, method of application and severity of the problem.

READ PRODUCT LABEL INSTRUCTIONS, TECHNICAL BULLETIN & SDS THOROUGHLY BEFORE USING. ALWAYS TEST FIRST.
KEEP SURFACE CLEAN AND DRY TO REDUCE THE POSSIBILITY OF SLIP & FALL ACCIDENTS AND INJURIES

