

PS15 - Remove Soap Scum, Water Deposits, Mildew

Remove Soap Scum, Water Deposits & Mildew from Porcelain or Ceramic Tiles

PRODUCT: **OXI-TREAT HD™**

EQUIPMENT: AquaBug Cleaning Kit, Scrub pad or brush, broom, bucket, clean water and cotton towels. Optional: Scrub machine, wet-dry vac.



PRECAUTIONS:

1. Read entire label, SDS & technical bulletin before using;
2. Wear appropriate skin & eye protection & use in a well ventilated area;
3. Use when surface temperature is between 4°C & 32°C;
4. Do not allow product to come in contact with non recommended surface;
5. Do NOT use on acid sensitive/polished surfaces;
6. Do NOT mix in metal buckets or containers;
7. Remove all metal jewelery before using.

PROCEDURE:

1. Sweep, vacuum, or wipe surface;
2. Slightly pre-wet surface with clean water;
3. Dilute **OxiTreat HD™** depending on the severity of the problem:
 - a) **LIGHT:** Dilute 1 part **OxiTreat HD™** to 15 parts clean water.
 - b) **MODERATE:** Dilute 1 part **OxiTreat HD™** to 10 parts clean water.
 - c) **HEAVY:** Dilute 1 part **OxiTreat HD™** to 5 parts clean water
 - d) **EXTREME:** Dilute 1 part **OxiTreat HD™** to 3 parts clean water.
4. Carefully apply the solution to surface with a sponge or a mop;
5. Allow minimum dwell time of 10 minutes. Longer dwell time may be required.
6. **DO NOT ALLOW THE PRODUCT TO DRY ON THE SURFACE;**
7. Scrub with a white nylon pad or scrub machine;
8. Remove the dirty solution with a wet vac or mop;
9. Rinse thoroughly with clean water;
10. Repeat the process as necessary.

Note 1: Heavily soiled areas may require longer dwell time and/or stronger solution.

Note 2: Add **MicroScrub™** to standing solution just prior to scrubbing to boost performance where required

Note A: Do not use **OxiTreat HD™** on marble, limestone, travertine or on other acid-sensitive tile or stone.

This recommendation is intended as a general guideline. The actual procedure requirements, dilution ratios, dwell time etc may vary depending on type of surface, method of application and severity of the problem.

READ PRODUCT LABEL INSTRUCTIONS, TECHNICAL BULLETIN & SDS THOROUGHLY BEFORE USING. ALWAYS TEST FIRST.

KEEP SURFACE CLEAN AND DRY TO REDUCE THE POSSIBILITY OF SLIP & FALL ACCIDENTS AND INJURIES